



Partlist

Part	Value	Device	Package	Library	Sheet
C1	22pf	C-EUC0805	C0805	programmer atmega	1
C2	22pf	C-EUC0805	C0805	programmer atmega	1
C3	100nF	C-EUC1206	C1206	programmer atmega	1
IC1	MEGA8-AI	MEGA8-AI	TQFP32-08	programmer atmega	1
LCD1	LCD_2X16	LCD_2X16	HY-1602F	programmer atmega	1
LED1	OK	LEDSMT1206	1206	programmer atmega	1
LED2	ERR	LEDSMT1206	1206	programmer atmega	1
Q1	7,3728MHz	CRYSTALHC49S	HC49/S	programmer atmega	1
R1	330	R-EU_R1206	R1206	programmer atmega	1
R2	330	R-EU_R1206	R1206	programmer atmega	1
R3	10k	R-EU_R1206	R1206	programmer atmega	1
R4	10k	R-EU_R1206	R1206	programmer atmega	1
R5	10k	R-EU_R1206	R1206	programmer atmega	1
R6	680	R-EU_R1206	R1206	programmer atmega	1
R7	0R	R-EU_R1206	R1206	programmer atmega	1
R8	0R	R-EU_R1206	R1206	programmer atmega	1
R9	0R	R-EU_R1206	R1206	programmer atmega	1
R10	0R	R-EU_R1206	R1206	programmer atmega	1
R11	0R	R-EU_R1206	R1206	programmer atmega	1
SV1	ISP	MA05-2	MA05-2	programmer atmega	1
SV2	Ser	MA04-1	MA04-1	programmer atmega	1
SV4	lcd lsb	MA06-1	MA06-1	programmer atmega	1
SV5	lcd msb	MA06-1	MA06-1	programmer atmega	1
T1		2N7002	SOT-23	programmer atmega	1
T2		2N7002	SOT-23	programmer atmega	1
T3		2N7002	SOT-23	programmer atmega	1
OK		SWITCH_TACT_6MM		programmer atmega	1
UP		SWITCH_TACT_6MM		programmer atmega	1
DOWN		SWITCH_TACT_6MM		programmer atmega	1
LEFT		SWITCH_TACT_6MM		programmer atmega	1
RIGHT		SWITCH_TACT_6MM		programmer atmega	1





